



RHH-IHB

Материал - оцинкованная сталь

Единицы измерения - мм.

Резьба	Наименование	Код	T - (Min-Max) (диапазон захвата)	A	HS +0,10	D +0,07 -0,10	B	K	L
M3	RHH-IHB-0315	719800315	0.5-1.5	6,60	5,00	5,00	6,00	0,60	8,50
M4	RHH-IHB-0420	719800420	0.5-2.0	8,30	6,00	5,90	7,00	0,50	12,00
M5	RHH-IHB-0525	719800525	0.5-2.5	8,70	7,00	6,90	8,00	0,50	13,00
M6	RHH-IHB-0635	719800635	1.0-3.5	10,50	9,00	8,90	10,00	0,60	16,00
M8	RHH-IHB-0835	719800835	1.0-3.5	11,30	11,00	10,90	12,00	0,65	17,50
M10	RHH-IHB-1040	719801040	1.0-4.0	12,80	13,00	12,90	14,50	0,75	21,00
M12	RHH-IHB-1240	719801240	1.0-4.0	14,80	16,00	15,90	17,50	1,00	24,00



RHH-IHB/SS

Материал - нержавеющая сталь

Единицы измерения - мм.

Резьба	Наименование	Код	T - (Min-Max) (диапазон захвата)	A	HS +0,10	D +0,07 -0,10	B	K	L
M3	RHH-IHB/SS-0315	719700315	0.5-1.5	6,60	5,00	5,00	6,00	0,60	8,50
M4	RHH-IHB/SS-0420	719700420	0.5-2.0	8,00	6,00	5,90	7,00	0,50	12,00
	RHH-IHB/SS-0435	719700435	2.0-4.0	8,00	6,00	5,90	7,00	0,50	13,00
M5	RHH-IHB/SS-0525	719700525	0.5-2.5	8,20	7,00	6,90	8,00	0,50	13,00
	RHH-IHB/SS-0540	719700540	2.5-4.0	8,20	7,00	6,90	8,00	0,50	14,50
M6	RHH-IHB/SS-0630	719700630	0.5-3.0	10,70	9,00	8,90	10,00	0,60	16,00
	RHH-IHB/SS-0650	719700650	3.5-5.5	10,70	9,00	8,90	10,00	0,60	17,50
M8	RHH-IHB/SS-0835	719700835	1.0-3.5	11,20	11,00	10,90	12,00	0,65	17,50
	RHH-IHB/SS-0850	719700850	3.5-6.0	11,20	11,00	10,90	12,00	0,65	19,70
M10	RHH-IHB/SS-1035	719701035	1.0-4.0	13,50	13,00	12,90	14,5*	0,75	21,00
	RHH-IHB/SS-1050	719701050	0.8-3.0	13,50	12,00	11,90	13,00	0,80	18,00
M12	RHH-IHB/SS-1240	719701240	1.0-4.0	16,00	16,00	15,90	17,60	0,70	23,50

Для заметок

